

TECHNICAL DATA SHEET

PURSAFE S5 CI SRC

Safety shoes

Article NO: G3176

Upper: polyurethane

outer material with air bubbles

Size: 38 - 47



Boots made of polyurethane, outer material with structure with air bubbles allows air circulation and provides thermal comfort throughout the day. Boots keep feet warm in cold and cool in warm weather. Thermal insulation up to -20°C. Retain flexibility even at -25°C while PVC and rubber boots at this temperature becomes harder. PU boots are also lighter, which means that they wear requires less effort and reduces the sweating. The sole is resistant to oils and fuels, antistatic and absorbs energy in the heel area.

Type and degree of protection:

Catanama	EN ICO 2024E
Category	EN ISO 20345
Thermal insulation	Х
Antistatic properties	X
Absorption of energy in the heel area	х
Sole with pattern- oil resistance	х
Water resistance	x
Safety toecap for toe protection	x
Puncture resistance (protective insole)	x
Slip resistance on ceramic tile floor with SLS and on steel floor with glycerol (SRC mark).	х















This personal protective equipment is in conformity with this harmonized European Standard:

EN ISO 20344:2011: Personal protective equipment - Test methods for footwear.

EN ISO 20345:2011: Personal protective equipment- Safety shoes.

Slip resistance on ceramic tile floor with SLS and on steel floor with glycerol (SRC mark).



Certified by notified body no. 0193 (Prüf- und Forschungsinstitut Pirmasens e.V., Pirmasens, Germany).

Certificate number 2000604 02 86.

Pairs in carton: 5

Carton weight: 12,0 kg Carton size: 0,098 m³

The shoes have to be perfect as for from and size, because they have rigid parts. The right size has to be found by measuring practically and carefully the shoes. The closing system has to be used correctly. The laces have to be tightened well without leaving too long free tops. The shoes have to be cleaned and treated with right, specific products, following the instructions for use. Do not keep footwear near heatings when not used and let them dry in a windy or room temperature. Before wearing and when cleaned, the shoes have to be controlled in order to find out visible defects existing, like closing system function, outsole profile's water, possible damages, etc. To define the right type of footwear to wear in every environment, the possible dangers and the place/ environment have to be indeded (e.g. construction industry, high temperatures, etc.). The shoes have to be stored correctly, keeping them in the proper packing.